

SAMSUNG



Samsung GALAXY S II

Quick Reference Guide Samsung GALAXY S II

Basic Operation











<b>On/Off</b>	<ul style="list-style-type: none"> <li>To activate, press and hold  until the screen display is turned on.</li> <li>To deactivate, press and hold  and select <b>Off</b>.</li> </ul>
<b>Dialing</b>	<ol style="list-style-type: none"> <li>In idle mode, press <b>Phone</b> → <b>Keypad</b> and using the virtual keyboard, enter the required telephone number, including the area code (if you entered a wrong digit, press  to delete).</li> <li>To dial, press .</li> </ol>
<b>Answer/End a call</b>	<ul style="list-style-type: none"> <li>To answer a call, drag  right to the triangular parentheses.</li> <li>To end the call, press <b>End Call</b>.</li> </ul>
<b>Silencing an incoming call</b>	Press and hold the bottom part of the volume key on the left side of the handset, until the ring is silenced.
<b>Action keys</b>	The option bar on the bottom part of the screen presents different action keys in accordance with the active feature and the telephone's operational mode.
<b>Main menu access and selecting actions</b>	<ol style="list-style-type: none"> <li>In idle mode, press <b>Menu</b> to display the main menu.</li> <li>From the displayed menu:                     <ul style="list-style-type: none"> <li>Press the desired menu or application to select and display the next menu, activation screen or to activate the application.</li> <li>Press the action keys at the bottom of the screen in order to perform various actions.</li> <li>Drag your finger right or left along the screen to display additional menu screens.</li> </ul> </li> </ol>

Operational Keys

	<ul style="list-style-type: none"> <li>When the phone is off, press and hold to activate the phone.</li> <li>When the phone is on, press and hold to display <b>Phone options</b>.</li> </ul>																
	Press to display the menu of available options in the current screen.																
	<ul style="list-style-type: none"> <li>Press to return to the idle menu.</li> <li>Press and hold to display the list of last used applications.</li> </ul>																
	Press to return to the previous screen.																
	<ul style="list-style-type: none"> <li>In idle mode, press up or down to adjust the ringing volume.</li> <li>During a conversation, press up or down to adjust the conversation volume.</li> </ul>																
<b>Special features when writing a message</b>	<p>When entering text using the virtual keyboard, the following keys will serve to:</p> <table border="1"> <tr> <td></td> <td>Enter a space; Alter text language (dragging)</td> </tr> <tr> <td></td> <td>Shift to symbol entry mode</td> </tr> <tr> <td></td> <td>Back to letter entry mode (from symbol mode)</td> </tr> <tr> <td></td> <td>Toggle caps lock/unlock</td> </tr> <tr> <td></td> <td>Delete</td> </tr> <tr> <td></td> <td>Start a new line</td> </tr> <tr> <td></td> <td>Enter by voice dictation (English only)</td> </tr> <tr> <td></td> <td>Change entry mode; Press and hold to access keyboard setting</td> </tr> </table>		Enter a space; Alter text language (dragging)		Shift to symbol entry mode		Back to letter entry mode (from symbol mode)		Toggle caps lock/unlock		Delete		Start a new line		Enter by voice dictation (English only)		Change entry mode; Press and hold to access keyboard setting
	Enter a space; Alter text language (dragging)																
	Shift to symbol entry mode																
	Back to letter entry mode (from symbol mode)																
	Toggle caps lock/unlock																
	Delete																
	Start a new line																
	Enter by voice dictation (English only)																
	Change entry mode; Press and hold to access keyboard setting																

<b>Using a browser</b>	<p>When surfing Internet sites:</p> <ul style="list-style-type: none"> <li>Press  to select an internet address from the lists of <b>Bookmarks</b>, <b>Most visited</b>, or <b>History</b>.</li> <li>Press  to select one of the following options:                     <ul style="list-style-type: none"> <li><b>New window:</b> Add a new browser window.</li> <li><b>Windows:</b> Select one of the opened browser windows.</li> <li><b>Browser brightness:</b> Change screen display brightness.</li> <li><b>Refresh:</b> Reload the displayed page.</li> <li><b>Forward:</b> Move ahead to a page in surfing history.</li> <li><b>More:</b> Access the following browser options: <b>Add bookmark</b>, <b>Add shortcut to home</b>, <b>Find on page</b>, <b>Page info</b>, <b>Share page</b>, <b>Downloads</b>, <b>Settings</b> and <b>Print</b>.</li> </ul> </li> </ul>
------------------------	---

## Operational Tips

<b>Stay Connected</b>	<p><b>Want to stay connected and updated all the time?</b> All you have to do is log on with your Google account, enter the main menu, press Gmail and enter the account.</p> <p><b>Don't have an account?</b> You will have one in just a few small steps.</p>
<b>Applications and Games</b>	<p><b>Want applications and games?</b> Log on to the Market directly from your phone, enter your Gmail account details once (or create a new account) and you will be able to download endless applications of all kinds, enjoying intuitive and free access.</p>
<b>Stay Updated</b>	<p><b>Want to stay updated?</b> Scrolling downwards on the status bar at the top of the screen, will expose current reports regarding e-mails, new software programs, messages, unanswered calls and more.</p>
<b>Personal Settings</b>	<p>To bring up a useful menu for adding Widgets, folders, changing wallpaper or creating shortcuts press and hold any free space on the screen.</p> <p><b>Want to change the location of an application in the home screen?</b> Press and hold the application icon to drag it to wherever you want it to go.</p>
<b>Adding pages and folders to the Main menu</b>	<p><b>Want to add screen pages or folders to the main menu?</b> Press  → <b>Edit</b>, then press and hold the application and drag it to the <b>Add folder</b> or <b>Add page</b> option.</p>
<b>Getting Organized</b>	<p><b>You can drag many programs into the folders that you create?</b> You can drag many programs into the folders that you create. Press and hold the folder name to change it.</p>
<b>Scrolling through the screen pages</b>	<p><b>Need to rapidly go to a page on the idle screen or main menu?</b> To rapidly browse between pages from the idle screen or application menu, drag your finger over the page numbers at the bottom of the screen.</p>
<b>Clock location in lock screen</b>	<p>To change the clock location in the lock screen, select <b>Menu</b> → <b>Settings</b> → <b>Display</b> → <b>Screen display</b> → <b>Clock position</b> → <b>Top</b> or <b>Middle</b> or <b>Bottom</b>.</p>
<b>Wallpaper effect for idle screen</b>	<p>To set a wallpaper effect for the idle screen <b>Menu</b> → <b>Settings</b> → <b>Display</b> → <b>Background effect</b> → <b>Dynamic</b> or <b>Movie</b>.</p>
<b>Search</b>	<p>Press  → <b>Search</b>, for a quick search through the Contacts, Google Search and the internet browser menu.</p>
<b>Keep quiet</b>	<p><b>Want to toggle quickly between profiles?</b> Press and hold  to switch between <b>Regular</b>, <b>Silent</b> or <b>Flight</b> modes or use the volume keys to toggle quickly between the Regular and Silent modes.</p>
<b>Rapid transition between applications</b>	<p>When using, press and hold  to quickly toggle between the active applications.</p>
<b>Access Main Menu during a Call</b>	<p>During a call, pressing  will take you back to the telephone's main screen.</p>
<b>Change Display Size</b>	<p>The telephone's "multi-touch" option enables you to enlarge/reduce the image, internet page or message display size by opening/closing two fingers on the screen.</p>
<b>Rejecting Call with Message</b>	<p>When accepting an incoming call, scroll the <b>Reject Call with Message</b> menu upward to select the desired rejection message.</p>
<b>Adding Contacts from Other Accounts</b>	<p>To synchronize contacts from other accounts, i.e. your Facebook account, select <b>Contacts</b> →  → <b>Find friends</b> → select an account.</p>
<b>Conveniently read messages</b>	<p>When reading messages, turning the device horizontally will display a split screen with a list of the messages received on the left and the content of the selected message on the right.</p>
<b>End call with the power button</b>	<p>To end a call using the power button, select <b>Menu</b> → <b>Settings</b> → <b>Call</b> → <b>Call answering/ending</b> → <b>The Power key ends calls</b>.</p>
<b>Button illumination</b>	<p>To change the duration of button illumination ( and ) , select <b>Menu</b> → <b>Settings</b> → <b>Display</b> → <b>Touch key light duration</b> → the desired illumination duration.</p>
<b>Wireless connection remote management</b>	<ol style="list-style-type: none"> <li>When connected to a wireless network, select <b>Menu</b> → <b>Kies air</b> → <b>Start</b>.</li> <li>In the computer browser, enter the URL address appearing in the device screen and approve the access request appearing on screen.</li> <li>Using the Kies Air application interface in the browser, manage the device contents.</li> <li>To disconnect, select <b>Stop</b> on the device.</li> </ol>
<b>Sharing media files in wireless communications</b>	<ol style="list-style-type: none"> <li>Select <b>Menu</b> → <b>AllShare</b>.</li> <li>Press  → <b>Settings</b> and adjust the DLNA feature settings.</li> <li>To activate files from your device on another one, select <b>My Device</b> → a media category → a media file → a media player. To activate files from another device on yours, select <b>Remote Device</b> → a device → a media category → a media file → a media player.</li> <li>Control file playback using the symbols on your device.</li> </ol>
<b>Using movement as shortcuts</b>	<p><b>Want to learn how to do things with movement?</b> Select <b>Menu</b> → <b>Settings</b> → <b>Motion</b> and use the <b>Tutorial</b> to learn how to do things with movements.</p>
<b>Edit Text</b>	<p>To change the position of your cursor when entering text, press the text in the entry field and drag the text input icon  to the desired location in the text.</p> <p>To select text, press and hold it and select <b>Select Word</b> or <b>Select All</b>. Drag the start and end cursors to mark the text that you wish to select and edit it, or select <b>Copy</b> or <b>Cut</b>.</p>